

Viterra's port loading facilities

	Outer Harbor	Inner Harbour	Port Lincoln	Wallaroo	Port Giles	Thevenard
Latitude	34°51'S	34°51'S	34°43'S	33°65'S	35°05'S	32°09'S
Longitude	138°30'E	138°30'E	135°50'E	137°37'E	137°55'E	133°39'E
Max. LOA	320m	225m	270m	200m	225m	180m
Max. beam	36.0m	32.2m	30.0m	32.0m	32.2m	28.0m
Depth alongside	16.2m	10.9m	15.0m	8.7m	14.7m	9.8m
Length of berth	320m	204m	347m	290m	340m	198m
Max. sailing draft	14.0m	9.3m plus tide	14.6m plus tide	8.5-9.0m	14.7m	9.0m
Ship loader type	Cleveland cascade chute travelling loader Trimming head attached to loader when hold trimming No. of belts: 1 No. of spouts: 1	1 travelling gantry loader Spout trimming only No. of belts: 1 No. of spouts: 1	2 travelling gantry loaders Spout trimming only No. of belts: 2 No. of spouts: 2	5 identical slewing loading booms with spouts attached (Operate 2 at a time) Spout trimming only No. of belts: 1 No. of spouts: 5	5 identical slewing loading booms with spouts attached No trimming heads available Spout trimming only No. of belts: 1 No. of spouts: 5	1 travelling gantry with retractable boom and spout attached No trimming heads available Spout trimming only No. of belts: 1 No. of spouts: 1
Air draft	24.4m	14.7m	22.3m	12.9m	15.5m	14.0m
Indicative loading rate (metric tonnes/hour)	2200tph	800tph	3000tph	800tph	1000tph	1000tph

For more information contact:

Western region

Port Lincoln
Phone: 08 8682 1888
Fax: 08 8682 6526

Central region

Balaklava
Phone: 08 8862 0200
Fax: 08 8862 0202

Eastern region

Bordertown
Phone: 08 8750 2800
Fax: 08 8752 2825

Adelaide region

Inner Harbour
Phone: 08 8447 3089
Fax: 08 8341 1679